

## Installation and Operating Instructions

### Special equipment with dimmer/timer for Lumiglas luminaires

#### 1. Push button function:

- Switch the light on or off by pressing the button once.

#### 2. Dimmer function:

- Switch on the light by pressing the button.
- Press the button and keep it pressed.  
The brightness changes.
- Release the push-button at the desired brightness.  
The setting is saved automatically.  
Note: The light flashes at maximum and minimum brightness.

#### 3. Timer function:

The Lumistar luminaire is supplied with an activated timer at the factory.

- Press the key:  
The timer is activated automatically. The lamp switches off after the programmed time has elapsed. If the dimmer function is used during running time, the timer restarts when the button is released.
- The time can be aborted by pressing the button a second time.

#### Deactivate/activate timer function

- The timer is deactivated or activated by pressing the button and simultaneously applying or switching on the mains voltage.

The light flashes to detect the status:

- 1 x flashing = timer off
- 2 x flashing = timer on

